

2015-19 FORD F150 / F250 / F350
5.0L, 2WD/4WD



LEGALITY NOTES

The installation of headers onto any vehicle must be performed in accordance with all governmental regulations that might pertain to the particular vehicle receiving the headers. Please call your Thorley Headers distributor if there are any questions regarding the legality of the installation. **These headers are not legal for sale or use on pollution controlled vehicles and are intended for off-road use only.**

THY-225Y-L

LONG TUBE TRI-Y HEADERS

2015-19 FORD F150 / F250 / F350
5.0L, 2WD/4WD

PARTS INCLUDED

Ref.	Description	Qty
1)	Driver Side Header Assembly	1
2)	Passenger Side Header Assembly	1
3)	Driver Side Connector Pipe	1
4)	Passenger Side Connector Pipe	1
5)	Hex Head Bolt, 3/8" 16 X 2 1/2	4
6)	Hex Nuts, 3/8" 16	4
7)	3/8" Flat Washers	8
8)	10mm X 1.25 X 55mm Flange Head Bolts	2
9)	2 1/2" Band Clamps	2

TOOLS REQUIRED

Ref.	Description	Ref.	Description
1)	3/8" Drive Ratchet and Extensions	5)	8mm, 10mm, 12mm, 14mm Wrenches
2)	7/8" Box wrench or O2 Sensor Socket	6)	Metric Allen Wrench Set
3)	9/16" Box Wrench and Socket	7)	WD40 or equivalent
4)	8mm, 10mm, 12mm, 14mm Sockets		

WARRANTY NOTES

- 1) The utmost care is taken at Doug Thorley Headers ("DTH") to maintain the highest standards of quality. However, DTH cannot control the installation of the product. For this reason the warranty covers only the replacement of the components, it does not cover labor for the installation.
- 2) The use of any type of "header wrapping" immediately voids the warranty. Using any sort of wrapping material on the headers destroys the tubing's ability to dissipate heat, causing very rapid deterioration of the composition of the metal and the subsequent failure of the headers.
- 3) Any chrome plating applied to DTH header components is a high-nickel chrome finish applied to retard corrosion. This is a commercial quality "heat" chrome designed to protect the metal from the environment only. This finish is not "show chrome" and is not intended for the sake of appearance. This high-nickel chrome will turn colors and approach black as it cooks into the metal. The initial brilliance of the chrome finish is not covered under the warranty. Contamination of the surface by foreign substances may produce other color patterns. This can be prevented by routine cleaning.
- 4) Retain all paperwork pertaining to the purchase of your DTH product. Save your receipt!
Your limited warranty is not valid without a receipt of purchase.

THY-225Y-L

LONG TUBE TRI-Y HEADERS

2015-19 FORD F150 / F250 / F350
5.0L, 2WD/4WD

INSTALLATION NOTES

- 1) It is important that you read the entire instruction sheet before beginning any installation.
- 2) Due to restricted room in the engine compartment your headers may come close to certain body and chassis components, this is normal for an installation of this type. However, a careful inspection must be completed to ensure that the distances and placement are reasonable and logical, especially with regard to electrical, fuel, and brake components.
- 3) Because of car-to-car variations, DTH strongly recommends that these headers be installed by an experienced installation shop that has welding and fabrication capabilities.

WARNING! Do not rely on chassis jacks for support during header installation.

The subject vehicle should be raised and supported with jacking equipment and jackstands or ramps intended for undercarriage auto maintenance. It is extremely dangerous to work under an improperly raised and/or supported vehicle.

WARNING! Make certain there is ample clearance around components such as brake lines, brake proportioning valves, fuel lines, hoses and pumps, and electrical components and wires. In some cases it may be necessary to relocate items that may be adversely affected by exhaust system heat.

NOTE: These procedures are documented on factory standard-equipped vehicles with original configuration compliance. Any modification of the subject vehicle may dictate modification to these procedures.

INSTALLATION PROCEDURE

DRIVER SIDE OE MANIFOLD REMOVAL

- 1) Disconnect the negative battery terminal.
- 2) Raise the vehicle at least 24 inches and support it with jack stands or other suitable supports.
- 3) Starting on the driver side, remove the air intake tube and air box.
- 4) Unscrew the O2 from the connector pipe and unplug the O2 from the top and remove the O2 sensor.

NOTE: Use caution when removing the O2, unplug first, twisting the wires could damage the O2 sensor.

THY-225Y-L

LONG TUBE TRI-Y HEADERS

**2015-19 FORD F150 / F250 / F350
5.0L, 2WD/4WD**

INSTALLATION PROCEDURE

- 5) Disconnect both of the connector pipes from the stock manifolds and remove. It may be necessary to loosen and remove the passenger side floor board heat shield.
- 6) Undo the nuts and remove the manifolds. Save the factory header gaskets and nuts as they will be reused with the new headers. You may need to remove some studs during install.
- 7) Clean all traces of carbon from cylinder head & header gasket if necessary.

DRIVER SIDE HEADER INSTALLATION

- 1) Install driverside header over studs and start all nuts. Install studs if they were removed.
- 2) Tighten nuts starting in the middle and work your way outwards.

PASSENGER SIDE OE MANIFOLD REMOVAL

- 1) Undo the nuts and remove the manifold. Save the factory header gaskets and nuts as they will be reused with the new headers. You may need to remove some studs during install.
- 2) Unscrew the O2 from the connector pipe and unplug the O2 from the top and remove the O2 sensor.
NOTE: Use caution when removing the O2, unplug first, twisting the wires could damage the O2 sensor.
- 3) With the motor safely supported, undo the two motor mount nuts (motor mount to frame)
- 4) Carefully jack up the side of the motor approximately 2".
- 5) Clean all traces of carbon from cylinder head & header gasket if necessary.

THY-225Y-L

LONG TUBE TRI-Y HEADERS

**2015-19 FORD F150 / F250 / F350
5.0L, 2WD/4WD**

INSTALLATION PROCEDURE

PASSENGER SIDE HEADER INSTALLATION

- 1) Install header over studs and start all nuts. Install studs if they were removed.
- 2) Tighten nuts starting in the middle and work your way outwards.
- 4) Safely and slowly lower the motor back down and tighten the two nuts.
- 5) Reinstall the factory connector pipes.
- 6) Reinstall all the O2 sensors back into the connector pipes and plug back in at the motor.
- 7) Reinstall the air intake tube and air box.
- 8) Double check all work, check all bolts and nuts to make sure everything is tightened and no wires are resting on the header.
- 9) Reconnect battery and start the engine. After engine is started check for leaks.
 - a) Retighten the header bolts to 35 ft/lbs after approximately twenty minutes operation.
NOTE: Remember the engine will be hot at this time. Protect yourself accordingly.
 - b) Check and retighten the header bolts to 35 ft/lbs after the first month of operation.
 - c) Follow the "Relearning Process" as described in your Owner's Manual.