

DOUG THORLEY HEADERS

BY SUMMIT INDUSTRIES

THY-119

Dodge Charger/ Magnum/ 300C
2005-06
5.7L HEMI



PARTS INCLUDED

- 1 - Passenger side header
- 1 - Driver side header

HARDWARE INCLUDED

- 1 - Dipstick spacer
- 16 - M8-1.25x30mm Hex bolt
- 16 - 8mm Star Lock washers
- 4 - 3/8"-16x2-1/2" Hex head bolts
- 4 - 3/8"-16 Hex nuts
- 4 - 3/8" Lock washers
- 8 - 3/8" Flat washers
- 1 - Passenger side header gasket
- 1 - Driver side header gasket

TOOLS REQUIRED

- 8mm, 10mm, 3/8" Wrenches
- 3/8" Sockets
- Ratchet and extensions
- Torque wrench
- Rust penetrant
- Rubber mallet

WARRANTY NOTES

- 1) The utmost care is taken at Thorley Headers to maintain the highest standards of quality. However, Thorley Headers cannot control the installation of the product. For this reason, the Thorley Headers warranty covers only the replacement of the components - not the labor for the installation.
- 2) The use of any type of "header wrapping" voids the warranty. Using any sort of wrapping material on the headers destroys the tubing's ability to dissipate heat, causing very rapid deterioration of the metal and the subsequent failure of the headers.
- 3) The chrome plating applied to all Thorley headers is a high-nickel chrome finish applied to retard corrosion. This is a "heat" chrome to preserve the metal. This finish is not "show chrome" intended for the sake of appearance. This high-nickel chrome turns colors and approaches black as it cooks into the metal. The brilliance of the chrome finish is not covered under the warranty. Contamination of the surface by foreign substances may produce other color patterns. This can be prevented by routine cleaning.

THY-119

Dodge Charger/ Magnum/ 300C
2005-06
5.7L HEMI

WARRANTY NOTES

- 4) Retain all paperwork pertaining to the purchase of your Thorley product. Save your receipt!
Your limited warranty is not valid without a receipt of purchase.

LEGALITY NOTE

The installation of headers onto any vehicle must be performed in accordance with all governmental regulations that might pertain to the particular vehicle receiving the headers. Please call your Thorley Headers distributor if there are any questions regarding the legality of the installation. **The Executive Order (“E.O.”) number for this part number is D-540-4.**

INSTALLATION NOTES

- 1) It is important that you read the entire instruction sheet before initiating any installation.
- 2) Thorley headers are designed to fit only factory installed engine and transmission combinations. We cannot guarantee that Thorley headers will fit in the case of “engine swaps” or “transmission swaps”.
- 3) Due to restricted room in the engine compartment, your headers may come close to certain body and chassis components. This is normal for an installation of this type. However, a careful inspection must be completed to insure that the distances and placement are reasonable and logical, especially with regard to electrical, fuel, and brake components.
- 4) Because of the requirement to raise the engine to facilitate header installation, the engine mounts should be carefully inspected at that point of the installation. It is highly recommended that questionable or deteriorated engine mounts be replaced during the installation of the headers. In some cases, the engine mounts need to be loosened and repositioned to provide optimum header clearance from some components.
- 5) Because of car-to-car variations, ***Thorley Headers strongly recommends that these headers be installed by a competent exhaust shop that has welding and fabrication capabilities.***

THY-119

Dodge Charger/ Magnum/ 300C
2005-06
5.7L HEMI

INSTALLATION PROCEDURES

WARNING! - Do not rely on bumper jacks or chassis jacks for support during header installation. The subject vehicle should be raised and supported with jacking equipment and jackstands or ramps intended for undercarriage auto maintenance. It is extremely dangerous to work under an improperly raised and/or supported vehicle.

WARNING! - Make certain there is ample clearance around components such as brake lines, brake proportioning valves, fuel lines, hoses and pumps, and electrical components and wires. In some cases it may be necessary to relocate items that may be adversely affected by exhaust system heat.

NOTE: These procedures are documented on factory standard-equipped vehicles with original configuration compliance. Any modification of the subject vehicle may dictate modification to these procedures.

- 1) Disconnect the battery.
- 2) Raise the front of the vehicle approximately 24 inches and support it with jack stands or other suitable supports. (**WARNING!** - Do not rely on bumper jacks or chassis jacks for support during header installation. The subject vehicle should be raised and supported with jacking equipment and jackstands or ramps intended for undercarriage auto maintenance. It is extremely dangerous to work under an improperly raised and/or supported vehicle.)
- 3) Spray all exhaust component fasteners with rust penetrant and allow to soak thoroughly to prevent possible breakage of bolts.
- 4) Starting under the vehicle, disconnect the Y-pipe from the exhaust manifold.
- 5) Carefully remove spark plug wires and the O2 sensors from the wiring harnesses.
- 6) Disconnect and remove the oil dipstick tube. Retain the bolt with the stud on end and nut, as it will be needed later.
- 7) Starting with the Driver side, support the engine in a safe manner and remove the four bolts from the motor mounts. Jack up the engine approx. 2". Remove the factory heat shield and remove the manifold and gasket.

THY-119

**Dodge Charger/ Magnum/ 300C
2005-06
5.7L HEMI**

- 8) Drop engine and reattach motor mounts and tighten securely.
- 9) On the Passenger side, Support the engine in a safe manner. Remove the two nuts that hold the motor mounts to the frame. Jack motor up about 2". Remove the factory heat shield and remove the manifold and gasket. Lower engine and re-install the two nuts to the motor mounts securely.
- 10) Clean all traces of carbon deposits from each of the cylinder head exhaust port surfaces.
- 11) Install new headers with the header gaskets using the supplied bolts and washers.
- 12) Re-Install dip stick tube using the stock bolt with the stud on the end and stock nut and the 1-1/2" spacer provided. Re-install the dipstick.
- 13) After all header bolts are in, starting in the middle and working your way out, torque to 30-31 ft. lbs.
- 14) Using Thorley supplied hardware, connect the factory connector pipe to the Thorley header and tighten the collector bolts securely.
- 15) Re-install the O2 sensors into the new headers and plug into the wiring harnesses.
- 16) Re-install all spark plugs and wires.
- 17) Check to make sure there is adequate clearance on plug wires, battery cables, wire looms, brake lines, hoses, etc.
- 18) Double check everything.
- 19) Reconnect the battery. Start the engine and check for leaks.
- 20) Because the header bolts will initially stretch when hot, we recommend adhering to the following steps:
 - a) Retighten the header bolts to 35 ft/lbs after approximately twenty minutes of operation. (Note: Remember the engine will be hot at this time. Protect yourself accordingly.)
 - b) Check and retighten the header bolts to 35 ft/lbs after the first month of operation.